Quick Guide

ZM-HE100



Please read this Manual before use

1. Precautions

- We are not responsible for any damages due to improper use.
- Product design and specifications may be revised to improve quality and performance.
- Avoid inserting any foreign objects into the device.
- Keep device away from heat sources, direct sunlight, oil, and humid environment.
- Do not let the device be wet. It may not be covered by Warranty.
- It may have problem if used near magnetic objects.
- Exterior damage during use is not covered by Warranty.

2. Specifications

Spec. \ Model	ZM-HE100
Case Material	Aluminum Alloy, Acryl, Poly Carbonate
Weight	96g
Dimensions	135.3(L) × 78.6(W) × 13.1(H) ㎜
Interface	USB 2.0

3. System Requirements

- CPU: Intel Pentium / 350 Mhz or above compatible CPU
- O.S: Windows XP SP3 or above / Mac OS X 10.0 or above

4. Components

ZM-HE100

Pouch



Screw Driver & Bolts 2pcs

Quick Guide

USB 2.0 Cable

5. Mounting a 2.5″ HDD



6. Connect to / Disconnect from PC

Connect device to PC's USB port using enclosed USB cable.
When disconnecting, please use ″Hardware Safety Removal″ on tray.